














Radio plugs / Part 1

Position	Image	Description	Part-No.
		AEG FG, AEG, FuG10 / Teleport N	1011001
	No Image available	AEG FG, AEG, FuG 11b / Teleport ES	1011002
	No Image available	AEG FG, AEG, FuG 10a / FuG 11a / FuG 13a	1011001-1
	No Image available	AEG FG, AEG, Teleport 9S / Teleport 10 / FuG 10b / FuG 13b (2 Nops)	1011004
	No Image available	AEG FG,AEG, Teleport 9S / Teleport 10 / FuG 10b / FuG 13b (3 Nops)	1011008
	No Image available	ALAN FG, Alan, Alan 451	1019001-4
	No Image available	ALINCO FG, Alinco, 2,5mm, stereo	1010001
		ASCOM FG, Ascrom, SE 140 / FuG 11b / SE 110 & Bosch, HFG88 / HFG168 / HFG 458	1013005
		BOSCH FG, Bosch, FuG 10 / FuG 10a / FuG 11b / FuG 13a	1014001
		BOSCH FG, Bosch, FuG 8a / FuG 8b / FuG 9	1014002

Attention: Connectors and Adaptors, available for digital radios are published in the "Compatibility table for digital radio".

valid from: 01.08.2008
Page 1 of 8

Position	Image	Description	Part-No.
		BOSCH FG, Bosch, HFG88 / HFG168 / HFG458 & Ascom, SE140 / FuG 11b / SE 110	1013005
		BOSCH FG, Bosch, PR11	1014005
	No Image available	DETEWE FG, DeTeWe, UFH 971	1017001 upon request
	No Image available	EADS FG, EADS, FuG 11b & Maxon, SL100	1018001-4
		ELIN FG, Elin, EP 860	1016001
		ELIN FG, Elin, EP 900	1016001-1
		ELIN FG, Elin, P 204	1016002
		Entel FG, HX400	1025001
		ERICSSON FG, Ericsson, P 200 / P 202 / P 204	1018001
		GCD FG, GCD, MT 209 / MT 118	1018002
		GRUNDIG FG, Grundig, FK 103	1018001-1





Attention: Connectors and Adaptors, available for digital radios are published in the "Compatibility table for digital radio".

valid from: 01.08.2008
Page 2 of 8

Position	Image	Description	Part-No.
	No Image available	GRUNDIG FG, Grundig, FK 109	1018002-3
	No Image available	HYT FG, HYT, TC 3000 / TC 3600 (FuG 11b)	1031002
	No Image available	ICOM FG, Icom, IC-02E / H2 / H6 / H12 / M12 / U12	1019002
	No Image available	ICOM Fg,Icom, IC-F31GS / IC-F31GT / IC-F41GS / IC-F51GS / IC-F51 / FuG 11b / FuG 13b	1019006
	No Image available	ICOM Fg,Icom, IC-F3S / IC-A3 / IC-F15 / IC-F25, straight	1019004
	No Image available	ICOM FG, Icom, IC-A2 / A20 / A21 / A22 / A24 / F / IC-F3, straight	1019003
	No Image available	ICOM FG, Icom, IC-P2E / IC-F3GS / IC-F4GS / U2 / H8 / U8 / F10 / H10 / H11 / U10 / M11 / U11 / F12 / H16 / U16 / H19 / U19 / F20 / F30 / F40	1019001
		KENWOOD FG, Kenwood, FUNKEY	1020002
	No Image available	KENWOOD FG, Kenwood, TH-22 / TH-25 / TK-250 / TK-350 / TK-259 / TK-359 / TK-3101 / TK-270 / TK-370 / TK-260 / TK2160 / TK-3160 / TK-3201 / TK-2170 / TK-3170 / TK-260N / TK-260G	1020001
		KENWOOD FG, Kenwood, TK-290 / FuG 11b / TK-280 / TK-380 / TK-2140 / TK-3140 / TK-2180 / TK-3180 / TK-7180 / TK-8180	1020003
	No Image available	MAXON FG, Maxon, SA 1155	1011006-1 upon request



Attention: Connectors and Adaptors, available for digital radios are published in the "Compatibility table for digital radio".

valid from: 01.08.2008
Page 3 of 8

Position	Image	Description	Part-No.
	No Image available	MAXON FG, Maxon, SL-70, SL-500, SL-600	1011006-3 upon request
	No Image available	MAXON FG, Maxon, SL 55	1018001-3
	No Image available	MAXON FG, Maxon, SL-10, SPX	1018001-2 upon request
		MOTOROLA FG, Motorola, GP320 / GP340 / GP360 / GP380 / GP 640 / GP680 / GP1280 / PRO7150 / HT/750	1021015-1
	No Image available	MOTOROLA FG, Motorola, DP3400 / DP3600	1021027
		MOTOROLA FG, Motorola, 12 PIN, for Adaptor	1021005
		MOTOROLA FG, Motorola, 6 PIN, for Adaptor	1021006
	No Image available	MOTOROLA FG, Motorola, Expo	1011006-2
		MOTOROLA FG, Motorola, GP300 / CP040 / CP140 / CP160 / CP180 / P110	1021001
		MOTOROLA FG, Motorola, GP900 / GP1200 / GP3600 / HT1100 / MT2100 / MTS2000 / MT2100 / MTP300 / MTX838 / PTX3600 / XTS3000 / XTS5000	1021007
	No Image available	MOTOROLA FG, Motorola, GP 328 / GP338 / GP344 / GP388 / GP688	1021012-4

Attention: Connectors and Adaptors, available for digital radios are published in the "Compatibility table for digital radio".

valid from: 01.08.2008
Page 4 of 8


Position	Image	Description	Part-No.
		MOTOROLA FG, Motorola, MX1000 / MX2000 / MX3000	1021010
		MOTOROLA FG, Motorola, Visar	1021012
	No Image available	MOTOROLA FG, Motorola, GM300 / GM340 / GM380 / GM360 Attention only 16 pol female plug for GM radios	1021018
		NIROS FG, Niros, TRX1012	1027001
	No Image available	Simoco FG, Simoco, SRP 8000 / SRP 8020 / SRP 8030 / SRP 8031 / SRP 9120 / SRP 9130	1022002
	No Image available	STANDARD FG, Standard, C736L / C836L	1018002-2 upon request
	No Image available	STANDARD FG, Standard, HX390	1019001-1 upon request
	No Image available	SIMRAD FG, Simrad, HT-51	1029002
	No Image available	TAIT FG, Tait, T3000	1026001
	No Image available	TAIT FG, Tait, 5010 / 5020	1026004
	No Image available	TAIT FG, Tait, Orca	1026003

Attention: Connectors and Adaptors, available for digital radios are published in the "Compatibility table for digital radio".

valid from: 01.08.2008
Page 5 of 8



TECHNICAL DATA

Position	Image	Description	Part-No.
	No Image available	YAESU / Stabo FG, Yaesu, Stabo / RTH2006 / RTH2010 7 FTH & Alan, HP105, straight	1019001-2
		YAESU FG, Yaesu, VX 246, angled	1019001-3

Attention: Connectors and Adaptors, available for digital radios are published in the "Compatibility table for digital radio".

valid from: 01.08.2008
Page 6 of 8

Radio adaptors / Part 2


Position	Image	Description	Part-No.
	No Image available	ICOM (inline) FG, ICOM adaptor, F31GS >>> Bosch couple, FuG 10a	1019006-1
	No Image available	KENWOOD (inline) FG, Kenwood adaptor, TK290 >>> AEG couple, FuG 10a	1020004
	No Image available	KENWOOD (inline) FG, Kenwood adaptor, TK290 >>> Bosch couple, FuG 10a	1020005
		KENWOOD FG, Kenwood adaptor, TK290 >>> Hirose couple, 12 pin (female plug)	1020006
	No Image available	MOTOROLA FG, Motorola adaptor, MX1000 Ex >>> Hirose couple, 12 pin (female plug)	1021009 upon request
	No Image available	MOTOROLA FG, Motorola adaptor, MX1000 >>> Hirose couple, 12 pin (female plug)	1021010-1
	No Image available	MOTOROLA FG, Motorola adaptor, GP344 / GP388 >>> Hirose couple, 12 pin (female plug)	1021011
	No Image available	MOTOROLA FG, Motorola adaptor, GP344 / GP388 >>> Motorola couple, Visar (female plug)	1021012-3
		MOTOROLA (inline) FG, Motorola adaptor, GP900 >>> Bosch couple, FuG 10a (female plug)	1021007-1
	No Image available	MOTOROLA (inline) FG, Motorola adaptor, GP900 >>> AEG couple, FuG 11b / Teleport ES (female plug)	1021007-4

Attention: Connectors and Adaptors, available for digital radios are published in the "Compatibility table for digital radio".

valid from: 01.08.2008
Page 7 of 8



TECHNICAL DATA

Position	Image	Description	Part-No.
	No Image available	MOTOROLA (inline) FG, Motorola adaptor, GP900 >>> AEG couple, FuG 10a (female plug)	1021007-2
		MOTOROLA FG, Motorola adaptor, GP900 >>> Hirose couple, 12 pin (female plug)	1021007-3

Attention: Connectors and Adaptors, available for digital radios are published in the "Compatibility table for digital radio".

valid from: 01.08.2008
Page 8 of 8